


## octaeco floor positioning of spacer brackets F 313 Cfl S1 for plinth panel

TI-DB-10.7


## technical information



The spacers are placed on the outer edges of the octaeco floor at each start and end position.

On the corner panel, the spacers are placed at each position facing the plinth panel.

The plinth panel is placed in front of the spacers and fastened with the skirting extrusion from above using self-tapping countersunk screws P 720/20.



All dimensions in mm!  
The drawing remains basically valid!